

POWERSDR™/OPENHPSDR USER NOTES

This document is intended to describe the operation of certain PowerSDR™ features that are unique to HPSDR or have been modified / improved and operate differently on HPSDR hardware than on other hardware platforms.

Table of Contents

POWERSDR™/OPENHPSDR USER NOTES	1
AGC – Automatic Gain Control (NROV, 2012-11-23).....	2
The Basics.....	2
AGC Presets.....	2
Panadapter Controls	3
Custom Settings	3
Gain Details / Example	3
AM/SAM – Demodulation (NROV, revised 2013-03-07)	4
AM – Modulation (NROV, 2012-10-23)	5
Automatic Noise Reduction (NROV, 2012-10-07)	5
Automatic Notch Filter (NROV, 2012-10-07).....	6
Transmit ALC (NROV, 2012-10-23)	6
Noise Blanker (NROV, 2013-02-05)	7
Panadapter – Deep and Wide FFTs (NROV, 2013-02-21)	8
Introduction	8
Controls.....	9
FFT Size & Sample Rate	9
384K Operation – Some Considerations (NROV – 2013-02-21)	10

AGC – Automatic Gain Control (NR0V, 2012-11-23)

The Basics

Received signals may vary in strength by several orders of magnitude. The AGC automatically adjusts the gain applied to signals such that the audio volume is relatively constant independent of the received signal strength. To maintain excellent audio quality, gain changes are not instantaneous; gain changes follow exponential curves defined by time constants. Gain changes LEAD changes in received signal strength—this ensures that the audio output never overshoots or undershoots the appropriate levels.

This is a single-attack, dual-decay system meaning that a single time constant is used to decrease the gain and two different time constants are available to increase the gain. The attack time constant and the normal-decay time constant are user selectable while the fast-decay time constant is set as an internal parameter. The fast-decay time constant is employed following a fast impulse, i.e., a noise “spike”, so as to prevent the AGC from blocking a weak signal during the time-span of a normal-decay from the transient.

“Hang” functionality is incorporated to delay an increase in gain in certain situations, for example during a brief pause in speech of a strong SSB station. This maintains quieting during the pause by holding the gain constant during the hang-time.

Gain Slope functionality allows a user-selectable amount of gain above the “knee” or “threshold” at which the AGC begins to limit gain. This allows, for example, a very strong signal to sound somewhat louder than a strong signal.

AGC Presets

Several presets are found under the AGC pull-down on the radio front-panel.

- Fixed: AGC is turned OFF. The gain is fixed rather than the AGC automatically adjusting it. The Fixed Gain adjustment appears in place of AGC Gain on the front-panel. Use care when switching to this mode! With no gain reduction applied by the AGC, very high volumes can result depending upon the Fixed Gain Setting.
- Long: The attack time-constant is 2ms; the normal decay time-constant is 2000ms, hang is enabled with a hang time of 2000ms. Note that the “time-constants” are really that, i.e., it takes several time constants for complete gain adjustment. The hang-time is NOT a time-constant, it is a fixed time.
- Slow: Attack $\tau = 2\text{ms}$; Normal Decay $\tau = 500\text{ms}$; Hang Time $t = 1000\text{ms}$.
- Medium: Attack $\tau = 2\text{ms}$; Normal Decay $\tau = 250\text{ms}$; Hang is DISABLED.
- Fast: Attack $\tau = 2\text{ms}$; Normal Decay $\tau = 50\text{ms}$; Hang is DISABLED.
- Custom: Uses the “custom” settings on Setup Form -> DSP -> AGC/ALC.

PanadAPTER Controls

There are two controls that can be enabled to appear directly on the panadAPTER—AGC Max Gain and Hang Threshold. The controls can be enabled in “Setup Form -> DSP -> AGC/ALC”. Note, however, that the HANG is permanently disabled and will not appear in certain of the AGC Presets.

The AGC Max Gain is the maximum gain that the AGC will apply to increase the strength of a signal. This operates somewhat like the RF Gain of an analog radio. By grabbing the box at the left-end of the “G” line, one would normally set this level a bit above the noise floor on the panadAPTER.

The “H” line is to set the hang threshold. If a signal has sufficient strength to cross the H line, a hang will be invoked. Moving this line to the top of the screen effectively disables Hang.

Custom Settings

Under “Setup Form -> DSP -> AGC/ALC”, the attack and normal-decay time-constants, hang-time, hang-threshold (also on the panadAPTER), Maximum AGC Gain (also on the panadAPTER and front-panel), and slope can be independently adjusted.

Slope has a range of 0dB to 20dB. At 0dB, there is no slope and all signals will be limited to the same output level. At 20dB of slope, an extremely strong signal could produce 20dB higher output volume than a signal just meeting the AGC threshold. Settings of 6dB to 10dB may be preferable.

Gain Details / Example


For those who really want to understand how the AGC controls gain, the following example is provided.

Shown below is the gain response (output versus input) for this system with an AGC Gain setting of 90dB. Four different potential output responses are shown corresponding to four different Slope settings. The Slope settings are the values in parenthesis for each output curve.

Note that, in each case, the Slope setting is the amount of available gain between the knee of the curve and the maximum output level. All curves converge at the maximum output level at the upper right corner of the graph.

As noted above, in this example, AGC Max Gain is set to 90dB. This value represents the gain below the respective knee of each curve. The 0dB-slope curve clearly displays that, at an input of -90dB, the output is 0dB, i.e., there's 90dB gain.

$$AGCT := \max_gaindB = 90$$



Note that if, while listening to a signal, you increase the slope setting, the volume of that signal will reduce. This is to “make room” for higher volumes of stronger signals. This effect is reflected in the above graph but may be a surprise to operators until understood.

AM/SAM – Demodulation (NR0V, revised 2013-03-07)

- For AM Demodulation & SAM Demodulation, the “Fade Leveler” function will often reduce fading and improve the audio for AM. It operates by removing the fading carrier and replacing it with a much more stable carrier. Note that if this function is used with the Automatic Notch Filter, you may wish to select the “Post-AGC” option for the ANF. Otherwise, the ANF will notch out the carrier before the AGC and therefore the carrier will not have the intended quieting and stabilizing effect.
- For SAM Demodulation, Sideband Selection (LSB+USB, LSB, or USB) is available. If interference exists on one side of the AM signal, the alternate sideband may be selected to avoid the interference. Selecting a single sideband also sometimes eliminates the “flutter” occasionally heard on AM signals.
- A “DC Block” option has been added on the Setup/DSP/AM-SAM tab. This option removes the carrier from the signal at the end of the audio processing chain. When doing WAV

record/playback in the AM/SAM modes, this option is recommended. Also, under Wave_File_Controls/Options, select Receive “Post-Processed Audio.”

AM – Modulation (NROV, 2012-10-23)

- As with all other modes, it is strongly recommended that for AM operation the transmit ALC be enabled.
- The carrier level control on the Transmit setup tab adjusts the ratio of carrier to audio.
 - The normal setting is 100.0. At this level, assuming sufficient mic gain, you will achieve 100% modulation. The ALC limits the audio such that you will not exceed 100% modulation. At this setting, with no modulation, the ALC meter should show -6dB.
 - When another station is receiving you with a synchronous detector, you may be able to reduce the carrier level and, assuming sufficient signal strength, the synchronous detector may still be able to lock on the signal and demodulate it correctly. Note that this reduction in carrier will produce distortion on a normal AM detector. At a carrier level of 0, you have no carrier, i.e., you are transmitting DSB.
 - If you wish to modulate at less than 100%, increase the carrier level above 100. The ALC will reduce the audio accordingly such that the total signal remains within the limits required by the HPSDR transmitter card.
- Note that the modulation algorithm prevents “carrier shift.” This means that the carrier level will NOT vary based upon the level of the modulation.

Automatic Noise Reduction (NROV, 2012-10-07)

- Expectations:
 - LMS Noise Reduction algorithms work best when the signals already have a good signal-to-noise ratio; they can be very effective in providing a quiet background under these circumstances. This is really their purpose.
 - It is unlikely that you will be able to pull an otherwise unreadable signal out of the noise with this type algorithm.
 - This algorithm is CPU intensive. The CPU load increases with the number of taps and with sample rate.
- Use:
 - Set the AGC Gain line just above the noise floor for best operation. (So AGC doesn't undo what the ANR is trying to do.)
 - Baseline values to try FOR 192K SAMPLE RATE:
 - Taps = 256 (increase to expand frequency range, generally reduces noise)
 - Delay = 64 (generally increase to reduce noise)
 - Gain = 100* (decrease to reduce noise)

- Leak = 100 (Increase to reduce noise)
 - *Lower values of gain may work very well on CW signals.
- The Pre-AGC position in the processing pipeline should generally be used. Post-AGC may work better in certain situations, for example, fast QSB.

Automatic Notch Filter (NROV, 2012-10-07)

- Expectations:
 - This algorithm is CPU intensive. The CPU load increases with the number of taps and with sample rate.
 - Increasing gain allows the algorithm to more effectively lock onto and notch carriers. HOWEVER, at higher gains the algorithm will begin to generate distortion on speech. I.e., there is a tradeoff between notching effectiveness and speech distortion.
- Use:
 - Baseline values to try FOR 192K SAMPLE RATE:
 - Taps = 256 (increase to expand effective frequency range)
 - Delay = 64 (lower to increase maximum effective frequency)
 - Gain = 200 (increase to more effectively lock onto carriers)
 - Leak = 100
 - The Pre-AGC position in the processing pipeline should generally be used. Post-AGC may work better in certain situations, for example, fast QSB, or when listening to AM with the Fade Leveler enabled.

Transmit ALC (NROV, 2012-10-23)

- ***IT IS STRONGLY RECOMMENDED THAT TRANSMIT ALC ALWAYS BE ENABLED.***
- With HPSDR, it is necessary to limit the signal transferred to the transmitter hardware to below a particular level; otherwise, very broadband splatter can result. The transmit ALC does this limiting.
- Proper operation of the ALC is indicated by the fact that the ALC Meter will not exceed 0dB.
- Normal settings for ALC parameters are:
 - Attack = 2ms
 - Decay = 10ms
 - Hang = 500ms


Noise Blanker (NR0V, 2013-02-05)

The console “NB” button now activates a new noise blanker algorithm. The noise blanker is used to remove short noise bursts from the stream of signal samples. To capture the noise bursts as completely as practical and to minimize damage to the frequency spectrum in the process, this algorithm operates as follows:

1. It “looks ahead” to see if a noise burst is coming.
2. When there’s a burst on the horizon, the signal level is gradually decreased, in a controlled fashion, to zero. The time from full signal to zero signal is “Transition” time.
3. The signal is held at zero for a “Lead” time before the burst arrives to catch as much as practical of the burst leading edge.
4. The signal is held at zero during the pulse and for “Lag” time after the pulse to catch as much as practical of the trailing edge.
5. The signal is then restored to full value using a controlled transition in “Transition” time.

The times (Transition, Lead, and Lag) as well as the Noise Blanker Threshold are all adjustable on the DSP/Options setup tab.

The following image taken from a simulation helps visualize what’s happening. The blue signal is the input to the noise blanker and the red signal is the output.



“Threshold” sets the peak level at which the input amplitude is judged to be a noise burst rather than just a signal. Therefore, if you set Threshold too low, you will begin to cut out normal signals. If you set Threshold too high, you won’t catch the noise burst.

Suggested settings for the times are all 0.1ms. However, if your particular noise problem is still partially sneaking through, try increased values.

The “legacy” noise blankers are still available on the “NB2” button. The thresholds for those can be adjusted under NB2 on the Setup/DSP/Options tab.

Panadapter – Deep and Wide FFTs (NR0V, 2013-02-21)

Introduction

The FFT processing for the panadapter displays has been enhanced to provide: (1) wider spectrum displays (for Hermes with firmware version 2.3 or greater, RX1 is > 1 Mhz; RX2 is > 350 KHz), (2) large FFTs / small bin-widths, and (3) frame rates up to sixty frames per second with any selectable spectrum size or bin-width. The smaller FFT bin-widths mean less noise per bin and a corresponding lowering of the noise floor for viewing weaker signals. The higher frame rates provide a more pleasing display as well as the opportunity to catch transient signals that may be missed with infrequent display updates.

These new capabilities come with some costs: (1) added memory utilization to store the additional samples required, and (2) an increase in CPU processing requirements. The additional memory is allocated when P*SDR is opened. However, the amount of additional CPU processing (if any) is dependent upon YOUR user settings. You can minimize CPU utilization by restricting your operation to the FFT depth and width limits that were in place prior to these enhancements, specifically: (1) use the minimum FFT size, and (2) restrict your spectrum view to less than ~188Khz. Also, you can reduce your frame rate as the FFT computations performed are directly proportional to the specified frame rate.

Averaging of multiple FFT results is useful to reduce the instantaneous noise. Four averaging modes are now available:

1. “Weighted – Log” averaging weights recent FFTs more heavily than older FFTs; however, no FFTs are ever completely removed from the average. This average is done after the data is converted to the log(dB) scale which is displayed. Therefore, the averaging appears “natural” on the displayed log scale. The relative weights of new versus older FFTs depend upon the Averaging/Time setting.
2. “Weighted – Linear” averaging operates similarly to “Weighted – Log”; however, it averages the FFT data before it is converted to the log scale. This has the interesting property of displaying a reasonable representation of peak values while still averaging to calm the noise floor.
3. “Window – Log” averaging operates on the data after the conversion to the log scale; however, it equally weights the last N FFTs, where N depends upon the Averaging/Time setting. In this way, old FFTs are completely dropped from the average as they move outside the time window.
4. “Window – Linear” averaging operates similarly to “Window – Log”; however, it averages the FFT data before it is converted to the log scale.

With larger FFT sizes and high frame rates, the averaging controls will have much less effect on the display.

Note that very large FFTs will produce displays that seem to move in slow motion. This occurs because the time window to capture the required number of samples for the FFTs is much larger.

Controls

Most controls are exactly the same as before, however, new setup tabs with additional controls are provided for RX1, RX2, and TX:

- Setup/General/Hardware Config: Checking the Limit Receivers/2-receivers box will limit the panadapter bandwidth to slightly less than the chosen sample_rate thereby reducing use of CPU cycles. Note that you can get approximately the same reduction in CPU cycles by just zooming in to restrict your viewed bandwidth. However, checking this box will also reduce your network bandwidth requirement.
- Console: The Zoom control works as before—but with extended range for Hermes users.
- Console: The Pan control works as before.
- Console: The AVG button turns averaging ON and OFF.
- Console: The Peak button turns peak capture mode ON and OFF.
- Setup/Display/RX1 and Setup/Display/RX2: Averaging/Time controls the timing for your choice of Averaging modes.
- Setup/Display/RX1 and Setup/Display/RX2: There are seven FFT sizes selectable using a slider. The corresponding bin-width is displayed.
- Setup/Display/RX1 and Setup/Display/RX2: The Window function for the FFT is selectable. Window functions control the leakage among frequency bins and result in variation in other properties of the display. For example, the Flat-top window offers exceptional amplitude accuracy while the Kaiser window is an excellent choice for general use.
- Setup/Display/TX: Window selection is provided.
- Setup/Display/TX: Polyphase may be enabled to slightly improve the resolution of frequencies.

FFT Size & Sample Rate

Note that bin-width is a function of BOTH the FFT Size AND the Sample Rate chosen in Setup/Audio. Larger FFT sizes of course produces smaller bin widths. Lower sample rates also produce smaller bin widths. However, lower sample rates mean that it takes longer to collect the samples and the display response will be correspondingly slower. The displayable spectrum is also proportional to the chosen sample rate.

384K Operation – Some Considerations (NR0V – 2013-02-21)

384K has now been added as a sample-rate option for Hermes users. 384K allows wider spectrum displays and more range for sub-receivers. However, processing more samples per second and achieving processing quality equivalent to that at lower sample rates require more CPU cycles and more memory for sample storage.

When increasing sample rate, you may want to consider your other settings in several areas.

- DSP Buffer Sizes – When you increase the sample rate, the cut-off of receive and transmit band-pass filters will be less sharp/defined unless you also increase the DSP buffer size. To allow you this option, two new DSP buffer sizes (8192 and 16384) have been provided as possible selections. Note that you can check your filter roll-off using the “Spectrum” display option.
- Automatic Notch Filter – To achieve the same frequency coverage, you may wish to increase the number of taps and delay settings when moving to a higher sample rate. The available ranges have been expanded.
- Noise Reduction - To achieve the same frequency coverage, you may wish to increase the number of taps and delay settings when moving to a higher sample rate. The available ranges have been expanded.
- Other DSP functions – There are several other DSP functions that will adjust automatically to the higher sample rate. They must, however, process more samples and will use correspondingly more CPU cycles.